

# NASA TECH BRIEF

## Ames Research Center




NASA Tech Briefs announce new technology derived from the U.S. space program. They are issued to encourage commercial application. Tech Briefs are available on a subscription basis from the National Technical Information Service, Springfield, Virginia 22151. Requests for individual copies or questions relating to the Tech Brief program may be directed to the Technology Utilization Office, NASA, Code KT, Washington, D.C. 20546.

### Measurement of Electron Density and Temperature in Plasmas

A simple technique has been devised to measure simultaneously the electron density and temperature of a plasma as a function of time.

The technique requires passage of two laser wavelengths through the plasma and measurement of the absorption of the light at these two wavelengths. The apparatus is shown in its simplest form in the figure;



beamsplitters BS<sub>1</sub> and BS<sub>2</sub> are dichroic mirrors which transmit radiation of wavelength λ<sub>1</sub> and reflect wavelength λ<sub>2</sub>. Thus, after passage through the chamber, energy of wavelength λ<sub>1</sub> proceeds through a narrow-band optical filter F<sub>1</sub> into detector D<sub>1</sub>, and energy of wavelength λ<sub>2</sub> passes through filter F<sub>2</sub> into detector D<sub>2</sub>. Both detectors are connected to suitable electronics (e.g., oscilloscopes) to enable recording of the intensity of radiation as a function of time.

When no plasma is in the chamber, the recorded signals provide I<sub>0</sub> values of transmitted laser energies; when plasma is present, laser energies will be attenuated and smaller transmitted intensities (I<sub>t</sub>) will be recorded. The attenuations are of the form  $I_t = I_0 e^{-Kl}$ , where  $l$  is the path length in the plasma and  $K$  is the total absorption coefficient for the plasma at the wave-

length under consideration. Of course, when dealing with pulsed plasmas, the attenuation of laser energy will be a function of time; thus, for a fixed path length, signal attenuations provide a value for the total absorption coefficient for a particular wavelength at a particular time.

The total absorption coefficient for a typical laboratory plasma can be shown to consist of four parts:

$$K = K_{e1} + K_{en} + K_p + K_r,$$

where  $K_{e1}$  is the absorption coefficient due to the electron-ion inverse bremsstrahlung (IB),  $K_{en}$  is the electron-neutral atom IB coefficient,  $K_p$  is the photoionization absorption coefficient, and  $K_r$  is the resonant coefficient. In general, each of these terms will depend upon the electron density  $n_e$ , temperature  $T$ , and the radiation wavelength. Using a long wavelength, the IB terms will dominate, i.e.,  $K \approx K_{e1} + K_{en}$ . For a measurement of both  $n_e$  and  $T$ , two wavelengths are used, for example, the nitrogen laser line  $\lambda_1 = 0.3371 \mu\text{m}$  and the CO<sub>2</sub> laser line  $\lambda_2 = 10.6 \mu\text{m}$ . For the long wavelength, the absorption coefficient has the functional dependence of the IB absorption coefficient:

$$K_1 = C_1 \lambda^3 T^{-1/2} n_e^2 \exp(hc/\lambda kT) g(\lambda, T)$$

where  $g(\lambda, T)$  is a slowly varying function of  $\lambda$  and  $T$ . At the shorter wavelength, the absorption coefficient behaves like the photoionization absorption coefficient and is roughly:

$$K_2 = C_2 \lambda^2 T^{-3/2} n_e g(\lambda, T).$$

For a series of temperatures, plots are prepared of the total absorption coefficient *vs* electron density for the two absorption coefficient relationships given

(continued overleaf)

above; each plot will consist of a family of curves correlating the absorption coefficient and corresponding electron density at fixed values of T. When a two-wavelength measurement is made, the two absorption coefficients,  $K_1$  for  $\lambda_1$  and  $K_2$  for  $\lambda_2$ , are determined. Then, entering the graphs at the measured values of  $K_1$  and  $K_2$ , the corresponding plotted values of electron densities and temperatures are compared and correlated by trial and error to obtain the best values for these functions in the plasma.

#### Notes:

1. The method is also applicable to measure either  $n_e$  or T individually. That is, if an independent measurement of  $n_e$  is made, for example with a laser electron interferometer, then a measurement of K using a long wavelength (e.g., 10.6  $\mu\text{m}$ ), will give the corresponding value of T. This is particularly attractive since it can be shown that for the long wavelength IB, the plasma need not be in

local thermodynamic equilibrium nor does one have to know the chemical species or elements in the plasma.

2. Requests for additional information may be directed to:

Technology Utilization Officer  
Ames Research Center  
Moffett Field, California 94035  
Reference: B72-10563

#### Patent status:

Inquiries concerning rights for the commercial use of this invention should be addressed to:

NASA Patent Counsel  
Mail Code 200-11A  
Ames Research Center  
Moffett Field, California 94035  
Source: Kenneth W. Billman, Paul D. Rowley,  
James Stallcop, and Leroy L. Presley  
Ames Research Center  
(ARC-10598)